

VelectriX



Instruction Manual: VelectriX Foldaway

CONTENTS

| | |
|------------------------------------|----------------|
| Safe Riding Recommendations | Page 2 |
| Pre-Ride Checklist | Page 3 |
| Display and Controls | Page 4 |
| Quick Guide to Folding | Page 6 |
| Battery Instructions | Page 7 |
| Maintenance | Page 9 |
| Warranty | Page 10 |
| Contact Details | Page 11 |
| Service Log | Page 12 |
| Model Specification | Page 13 |




Safe Riding Recommendations

1. Please ensure you are familiar with, and follow all traffic laws and regulations for your state. Please remember you may need to review these when travelling interstate.
2. Always wear a bicycle helmet when riding your bike.
3. Don't lend your bike to anyone who is unfamiliar with it.
4. As with all bikes it is important that you stay within safe limits and speeds. If you feel you are travelling too quickly for the road conditions, then slow down!! High speeds will increase risk of injury in the event of an accident.
5. Please read and become familiar with the "Pre-Ride Checklist" in this manual before riding your bike.
6. Switch the lights on your bike ON, when riding at all times of the day or night. If your bike doesn't have lights fitted as standard, it is recommended that you purchase them and fit before riding.
7. Your VelectriX bike must be returned to your servicing dealer after 250kms or 6 weeks from date of purchase, whichever comes first, to re-tension the spokes. Spokes should then be re-tensioned every 1500kms.

Pre-Ride Checklist

1. Check your bike for any loose nuts, bolts or fixings.
2. Check tyre pressures on your bike are correct. Please always refer to the tyre manufactures suggested levels on the side of the tyre. The following can be used as a guide only: VelectriX Foldaway (40-65psi).
3. Check the tyres on your bike for any visible damage, wear and tear or bald spots.
4. Check that the brake levers have been installed correctly on your bike. The left hand brake lever should operate the rear brake and the right hand brake lever should operate the front brakes.
5. Check the brakes are working effectively to stop your bike and the power from the motor halts when the brakes are on.
6. Check that your bike is fitted with a working bell and reflectors.
7. Check that the wheel nuts or quick release skewers on your bike are tight.
8. Check that the electronic functions on your bike are working.
9. Check that the handlebars and stem are tightened.
10. Check that all bags, baskets, boxes, etc. are securely fastened.
11. Check that your battery has sufficient charge for your ride.

LCD Display and Controls


Your electric bike is equipped with a LCD display, mounted on the left side of the handlebar, and is controlled with 3 easy to use buttons  (POWER),  (UP) and  (DOWN).



Turning the Battery On/Off

To ride with assisted power, you must first switch the battery on. This is done by simply pressing the power button located on the top of the battery. You will hear a short double beep and the green lights will appear.


Turn On The LCD Display

With the battery turned on, you can now turn on the LCD display. Push and hold the  POWER button, positioned on the top left hand side of the LCD display, for 2 seconds, until the display lights up and switches on.



Turn The Lights On/Off

Press & hold the  (UP) button on the display for 2 seconds.

Walk Mode

Press and hold the  (DOWN) button and the bike will be powered to 6kph walking speed. Simply release the button to stop, this is a handy function for walking with the bike up steep inclines.

Riding With Pedal Assisted Power

There are 5 pedal assist settings on this bike, level 1 being the slowest speed and level 5 the fastest (level 1 pedal assist is automatically selected when the display turns on). Simply push  (UP) and  (DOWN) buttons to change between the levels. Pedal assist does not work in level 0 (zero). To stop the motor engaging, simply stop pedalling or pull on the brake lever to engage the brakes.






Riding With Throttle Control

The bike is equipped with a hand throttle that can be used in pedal assist levels (1-5), including 0 (zero).

Automatic “Power Cut Off” Feature

This model is fitted with e-bike safety brake levers, which means that the power to the motor will immediately disengage when either the left or right hand side brake lever is used.

Other LCD Display Features

The LCD display, when turned on, will show speed, max speed, average speed, odometer, trip meter, trip time, battery capacity and level of assisted power (0-5). To change the information displayed (i.e speed, odometer, trip meter) simply push the  (POWER) button for 0.5 seconds. To reset the trip time and/or trip meter, hold the  (UP) &  (DOWN) buttons together and then push  (UP) button to select Y (yes) and then to confirm data reset, push & hold  (POWER) button for 2 seconds.

Quick Guide To Folding The Bike

Step 1. Fold pedal

To fold the pedals simply push the pedals inwards towards the bike frame and push the pedal up or down.



Step 2. Fold Handlebar

To fold the handlebar, twist the knob (at the front of the stem) counter clockwise and then gently let the handlebar fold downwards onto the wheel.



Step 3. Fold Bike In Half

Open the folding latch (located in the middle of the frame) and swing the bike to the around to the left until the magnets on the front & rear wheels touch. Make sure that the bike stand is up.

Battery Instructions

Lock/Unlock Battery

This bike is supplied with a set of keys, which are needed to lock/unlock the battery from the bike. The lock is located at the base of the battery on the left hand side of the bike. Simply turn left or right to lock/unlock.



Removing The Battery From The Bike

To remove the battery, unlock the battery (make sure to remove the key before removing battery), remove the seat post and slide the battery vertically out from the bike. When reattaching the battery make sure to lock the base to avoid unnecessary power failures or damage.



Charging The Battery

You can charge the battery on or off the bike, but first make sure that the battery is turned off (hold the button on top of the battery until you hear a short beep and the LED lights disappear). Now, plug the battery charger (supplied with this bike) into the charging port, which is positioned towards the top of the battery on the right side. Once connected to the battery the charger can then be turned on at the power socket. A GREEN light will indicate when the battery is fully charged. Max charge time is 4 hours.



The Battery Charger

ONLY use the battery charger supplied with this bike.



Maintenance

1. Your VelectriX bike should be returned to your servicing dealer for servicing and a thorough inspection once every 9 months or 1500kms, whichever comes first. Excluding the electronics, motor, battery and wiring, your VelectriX bike is a normal bike, with normal components. Your dealer will be able to explain to you the general care and maintenance required for the components of your bike.
2. Once a month lubricate all pivot points on your derailleur and derailleur pulleys with suitable chain lube.
3. You can clean your bike with warm soapy water, however, please do not submerge any electrical components or use a high pressure hose. You can wipe dry the bike with a cloth.

Warranty

All VelectriX bikes are covered by the following warranty and conditions of use:

| | |
|-------------------------|---|
| Battery | 2 years |
| Motor | 2 years |
| Frame | 5 years |
| Other Components | 1 year (excluding consumables: cables, tyres, tubes, hand grips). |

- The warranty is only valid for the first owner and is not transferrable.
- The warranty commences from the date of purchase and proof of purchase must be provided to cover any warranty parts.
- All commercial use is excluded.
- All Accidental damage is excluded.
- All damage caused from misuse is excluded.
- All repairs must be completed by a VelectriX dealer.
- The bike must be serviced every 1500kms or every 9 months, whichever the sooner.

Contact Details

If you have any questions, concerns or technical issues with any VelectriX product please contact your VelectriX dealer immediately.

Dealer Name:

| | |
|-----------------------|--|
| Dealer | |
| Contact Number | |
| Address | |
| Sales Person | |
| Sales Date | |

VelectriX Australian Service Centre Contact Details:

VelectriX Pty Ltd

Phone: 1300 530 031

Visit: 10 Capital Place, Birtinya, Qld, 4575

Website: www.velectrix.com.au

Email: store@velectrix.com.au

Service Log

| Date | Km | Notes |
|------------------|-----------|-------|
| | | |
| Next Service Due | Date: / / | OR Km |

| Date | Km | Notes |
|------------------|-----------|-------|
| | | |
| Next Service Due | Date: / / | OR Km |

| Date | Km | Notes |
|------------------|-----------|-------|
| | | |
| Next Service Due | Date: / / | OR Km |

| Date | Km | Notes |
|------------------|-----------|-------|
| | | |
| Next Service Due | Date: / / | OR Km |

| Date | Km | Notes |
|------------------|-----------|-------|
| | | |
| Next Service Due | Date: / / | OR Km |

Model Specification

VelectriX Foldaway

| | |
|---------------------------|---|
| Frame: | Aluminium VelectriX Foldaway |
| Size: | 40cm |
| Fork: | Aluminium fixed front fork |
| Colour: | Satin black |
| Tyres: | Kenda K Shield 20" x 1.75" |
| Brakes: | Tektro v brakes |
| Gears: | Shimano Nexus 3 speed gear hub |
| Motor: | 36 volt 200 watt front hub motor |
| Battery: | 36 volt Panasonic 8.8ah lithium ion |
| Battery Charger: | Kushan ST Electronics Li-Ion STC-8108L. 3a 240V |
| Maximum Speed: | 25 km/h |
| Weight: | 19.5kgs (inc. battery) |
| Range: | Up to 45kms |
| Carrying Capacity: | 110kgs (including battery, rider & accessories) |

